

REED

Model SW600 Stopwatch

Features

- Stopwatch/chronograph mode with 1/100th second resolution
- Displays hour, minute, second, and day of the week
- Programmable alarm and snooze functions
- High contrast digital display
- Records real time and split times
- 48" nylon lanyard



Normal time display mode

Shows minute, second and day of the week. It also allows you to turn the alarm on or off (see **Alarm On/Off**).

When you are in Normal Time Display mode (Figure 1), press

- **SPLIT/RESET** button to see the Alarm Time
- **MODE** button to change the Mode to Stopwatch Mode
- **START/STOP** button to show month, day of the week

Stopwatch function

Make sure stopwatch is in Normal Time Display mode. If the current display is not the Normal Time Display mode, press the **MODE** button until SU, FR and SA starts flashing together along the top of the LCD (Figure 2).

Accumulated elapsed time measurement:

Make sure the timer is reset back to 0:00:00 by pressing the **SPLIT/RESET** button.

1. Press the **START/STOP** button to start and stop the timer.
2. Press the **SPLIT/RESET** button to reset the timer back to 0:00 00.

Split time measurement:

Make sure the timer is reset back to 0:00:00 by pressing the **SPLIT/RESET** button

1. Press **START/STOP** button to start the timer.
2. Press **SPLIT/RESET** button for split time.
3. Press **SPLIT/RESET** button again to release the split.
4. Press **START/STOP** button to stop the timer.
5. Press **SPLIT/RESET** button to reset the timer back to 0:00 00.

Measurement between two competitors:

Make sure the timer is reset back to 0:00:00.

1. Press **START/STOP** button to start the timer.
2. Press **SPLIT/RESET** button to start the split time.
3. Press **START/STOP** button to stop the split time.
4. Press **SPLIT/RESET** button to view the split time.
5. Press **SPLIT/RESET** button again to reset the timer back to 0:00 00.

Alarm on/off

To turn the alarm on, press the **MODE** button until the display returns to the Normal Time Display mode. Once the Normal Time Display appears, press and hold the **SPLIT/RESET** and **START/STOP** buttons simultaneously. The  icon will appear which means the alarm is turned on.

To turn the alarm off, follow the same procedure as above until the  icon disappears.

Figure 1





Figure 2



Alarm Setting:

1. Press **MODE** button until MO and the hour digit(s) start flashing on the display.
2. Press **START/STOP** button to change the hour digit(s).
3. Press **SPLIT/RESET** button to confirm the hour selected. Then the minute digits will flash.
4. Press **START/STOP** button to change the minute digits.
5. Press **MODE** button to go back to the Normal Time Display.

Snooze Function

Snooze Function ON:

When the alarm is activated, press the **SPLIT/RESET** button to turn the alarm OFF. After 5 minutes, the alarm will activate again.

Snooze Function OFF:


To deactivate snooze function, press the **START/STOP** button when the alarm goes off. This turns the alarm and snooze functions OFF.

The alarm and snooze functions will turn OFF after one minute if no button is pressed.

Setting normal time display

1. Press the **MODE** button until you see TU and the second digits flashing (Figure 3).
2. Press the **START/STOP** button to set the second digits back to 00. To select the minute digit(s), press the **SPLIT/RESET** button once, then press the **START/STOP** button to set the desired minutes.
3. Press and hold the **START/STOP** button to scroll through the minutes (Figure 4).
4. Press the **SPLIT/RESET** button to confirm the selected minutes and change the hour digit(s). You will see the hour digit(s) flashing and one of the following letters on the right side of the LCD (where the seconds digits used to be) (Figure 5):

- A – 12 hour clock, AM time
- P – 12 hour clock, PM time
- H – 24 hour clock



Changing the HOUR digit(s):

1. Press the **START/STOP** button or press and hold the **START/STOP** button to scroll to the desired hour digit.
2. For 12 Hour format, press the **START/STOP** button and set desired hours in AM (A) or PM (P).
3. For 24 Hour format, press the **START/STOP** button until 12 P has passed, and an "H" appears on the right side of the LCD. Continue to press the **START/STOP** button and change hour figure.

Hour Chime (stop watch beeps once every hour on the hour)

To set the Hour Chime ON, press and hold **SPLIT/RESET** then press **MODE** (while continuing to hold **SPLIT/RESET**) until the days of the week appear on the top of the LCD. To turn Hour Chime OFF press **MODE** (while continuing to hold the **SPLIT/RESET** button) until the days of the week switch OFF.

Setting the date and day of the week

To change the day figure:

After setting the hour, press the **SPLIT/RESET** button again. The day will flash; change the day digit(s) by pressing the **START/STOP** button.

To change the month figure:

Press the **SPLIT/RESET** button again. The month figure will flash; change the month digit(s) by pressing the **START/STOP** button.

To change the day of the week:

Press the **SPLIT/RESET** button again. The day of week figure will flash; change the letter configuration by pressing the **START/STOP** button. (Starting with "SU" – Sunday, at the very top left of the LCD).

To confirm all time and date settings, press the mode button

NOTE: To change any of the above, press the **SPLIT/RESET** button and follow all of the above procedures.

To view the date

Go back to the Normal Time mode display by pressing the **MODE** button. Press the **START/STOP** button to view the date.

REED Instruments

1-877-849-2127 | info@reedinstruments.com | www.reedinstruments.com